The methodology for erection of the fencing will be as follows

1. Agree line of fence.
2. Set Out Post positions using prescribed centres, positions will be marked on ground using line marker paint.
3. Scan excavation areas for presence of services.
4. Excavate to receive posts, approx. 600mm deep x 200mm x 200mm
    a. In soft ground this will excavated by hand or auger attachment to mini excavator.
    b. In hard ground an excavator and hydraulic braker may be required.
5. Arisings to excavations to be landscaped or removed from site.
6. Timber rails to be attached to posts and trestles used to support rails during erection, posts to hang into holes.
7. Compact concrete into holes beneath and around posts, checking for plumb/level and line as works proceed.
8. Remove trestles once concrete set.
9. Tidy area and remove debris equipment etc

I trust this will suffice, should you require any further information, please do not hesitate to contact me.

Regards,

Gordon

Gordon Cartwright BSc CEng MICE
Director

Main Office Tele – 0141 375 7690
Website – www.go-wright.co.uk

Unit 7 Dunrobin Court, 14 North Avenue, Clydebank Business Park, Clydebank, G81 2QP